

火箭降落伞火焰信号

Rocket parachute flare

型号： JH1-300-86 (HR-3)




1	外型尺寸:	Φ 46*245mm	4	发光时间:	≥ 40 s
	Size			Burning time	
2	火焰颜色:	发出明亮的红光 Burn with red flare	5	发光光强:	≥ 30000 cd
	Flare colour			Light intensity	
3	发射高度:	≥ 300m			
	Fired altitude				

操作说明及维护保养手册

Rocket parachute flare

一. 操作说明 Instruction


①



垂直向上，去掉下盖。

Direct mark "TOP", upwards, remove bottom cap.


②



将信号举过头顶，抽出拉绳，用力拉出。

Hold signal over your head, pull out ignition line and pull hard.

③



双手握正，两秒后射出。

Hold signal firmly and upright with both hands, after 2s the rocket will fire.

* 注意 *

- ◆ 仅供船舶救生时使用
- ◆ 施放方向切勿对人
- ◆ 超出有效期请勿使用

* Warning *

- ◆ Use for distress signal only
- ◆ Don't direct outlet to person
- ◆ Use before the expiry date

二. 维护保养手册 (Maintenance Manual)

1. 储存温度 (storage temperature): $-30^{\circ}\text{C} \sim +65^{\circ}\text{C}$ 。
2. 不可用火烧 (No burning)。
3. 不可加热 (No heating)。